

## How to Disengage

**1** Always start by disengaging on the long side



**2** Grab the planks with both hands and gently lift at the same time until the planks disengage



**3** Place the planks gently on the floor



**4** To disengage on the short side, slide the planks the opposite direction



**5** Press the planks gently while sliding



**6** Continue sliding until the planks are fully separated



\*Do not pull plank up to disengage end joints. This will damage the locking mechanism.